



G-CRAC™ Filtration Media

G-CRAC™ is compatible with all processing solvents. Suggested for in-line CRC application or containers that accept granular carbon. Minimum suggested amount is 10% m/m of estimated extract in solution.

Safety

SDS Sheets: Available upon request on all chemicals used in this process.

Preparation

Required Materials:

G-CRAC™ Filtration Aid, Winterization Aid
In-line Filtration Housing

Procedure

1. Load filter media into filtration housing or solution.
2. Ensure that media is secured in filtration housing.
 - a. 1 micron mesh screen works well to secure filtration media.
3. G-CRAC™ does not need to be wetted prior to use.
4. Run filtration using polar or non-polar solvent.
 - a. Avoid saturation and maintain flow.
5. Follow disposal instructions in SDS

Contact info@mediabros.store for additional information and questions.